

INTER[®]



Tel: + 48 52 371 55 76

Tel: + 48 52 371 91 95

Fax: + 48 52 371 91 99

www.jmpinter.com

export@jmpinter.com

ACTION / TREEWOR TOP

EN 361

IMPORTANT POINTS

In order for this product to meet all your requirements, we ask you BEFORE EACH USE, to follow the instructions in this manual.

Disregarding the instructions described in this manual could give rise to some serious repercussions. We advise that you re-read these instructions from time to time. In addition JMP International declines all responsibility for any use, storage methods or maintenance carried out in any other manner than that described in this manual.

If the buyer is not the end user, it is important that these instructions are given to the latter. Check that the PPE you have acquired is compatible with the recommendations of all other components of the fall arrest system. It is necessary to be completely sure before use that the recommendations specific to each element associated with this product, such as defined in their instructions, are respected. Whenever possible, it is strongly advised to personally attribute the PPE to an individual user. While in use, protect your PPE against all risks connected with the work environment: thermal, electrical, or mechanical shocks, acid discharges, etc.

USE

ACTION/TREEWOR TOP chest harnesses are components of a complete fall-arrest system and cannot be used alone. Only the seat harness type TREEWOR or ACTION BELT combinations that are defined as compatible with EN 361. This product cannot be used for any purpose other than that for which it is designed.

Verify that this product is compatible with the other elements of the system in your application (compatible = good functional interaction). Equipment used with your harness must meet current standards in your country (e.g. EN 362 carabiners).

Installation on the seat harness

Follow the instructions in the drawings – see pic.2. Thread the adjustment buckle properly. Make sure to correctly stow the extra webbing (folded flat) in the retainers. Chest-seat harness connector: do not use it to attach a lanyard or energy absorber. ATTENTION DANGER, it must always be used with the gate closed and locked. Its strength is

greatly reduced if the gate is open. Systematically verify the gate is closed by pressing it with your hand. Contaminants such as mud, sand, paint, ice, dirty water, etc. can prevent the locking system from working. Your harness must be adjusted to fit snugly to reduce the risk of injury in case of a fall. You must move around and hang in the harness from each attachment point, with your equipment, to verify that the harness fits properly, provides adequate comfort for the intended use and that it is optimally adjusted.

EN 361 Fall arrest attachment point

Full body harness for fall arrest are component of a fall arrest system in accordance with the EN 363 standard (personal fall arrest systems). It must be used in conjunction with EN 795 anchors, EN 362 locking carabiners, EN 355 energy absorber, etc.. Only dorsal and sternal points may be used to attach a fall arrest system, for example a mobile fall arrester, an energy absorber, or other system described in the EN 363 standard. For ease of identification, these points are marked with the letter 'A'. Clearance: amount of free space below the user. The clearance below the user must be sufficient to prevent the user from striking any obstacle in case of a fall. Specific details on calculating clearance are found in the technical notices for the other components (energy absorbers, mobile fall arrester, etc.). See pic. 5 and 6.

ATTENTION

Activities at height are dangerous and can bring about serious accidents and injuries. We remind that you are personally responsible in the case of an accident, injury or fatality to either yourself or a third party during or following the use of one of our products. It is recommended that training in the use of our products is done under the supervision and instruction of a competent and experienced person. Ensure that you have been adequately trained in the use of this PPE and make sure that you have fully understood how it works. If there is any doubt, do not take any risks but seek advice. A good physical condition is obligatory in order to carry out work from a height.

IMPORTANT:

Before each use user have to carry out a visual examination in order to assure the integrity of the PPE. Check all webbings, especially at the attachment points, at the adjustment buckles, and at the safety stitching. Any PPE that has been subjected to a fall must not be used. Never try to modify or repair a piece of PPE yourself; only the manufacturer or a repair centre are able to carry out these repairs. These instructions must be kept with the product.

This PPE must be examined at least once a year by the manufacturer/distributor or by a competent person. The check must be recorded on the table which can be found on the back of this instruction. Confirmation of this review must be found in the Charter of the User of this product

Anchorage point:

It is preferable to use an anchorage point situated above the user. If possible use structural anchorage points that conform to the standard EN 795 (minimum strength of 12 kN) or EN516 *minimum strength 10kN) intended for this purpose. The clearance below the user must be sufficient to prevent the user from striking any obstacle in case of a fall. Specific details on calculating clearance are found in the technical notices for the other components (energy absorbers, mobile fall arrester, etc.).

ADDITIONAL INFORMATIONS

You must have a rescue plan to rapidly implement it in case of difficulties encountered while using this equipment. In a fall arrest system, it is essential to check the required clearance below the user before each use, to avoid any impact with the ground or an obstacle in case of a fall. Make sure that the anchor point is correctly positioned in order to limit the risk and the height of a fall. A fall arrest harness is the only device enable to protect user against fall down in a fall arrest system. WARNING: ensure that your products do not rub against abrasive or sharp surfaces. Inert suspension in a harness can result in serious injury or death. The instructions for use for each item of equipment used in conjunction with this product must be respected. The instructions for use must be provided to users of this equipment in the language of the country in which the product is to be used. Make sure the markings on the product are legible.

While using the textile elements must be protected before contact with oils, solvents, acids and alkalis, open flame, splashes of hot metal and sharp objects. It is forbidden to make any repairs or modifications to the equipment itself. Making any repairs or changes or additions should be entrusted with the equipment manufacturer or a competent person, authorized by the manufacturer. Equipment may be stored and used at temperatures from -40 °C to 80 °C.

MAINTENANCE AND STORAGE

Good maintenance and storage of your PPE will prolong the working- life of your product, while ensuring your safety:

- The harness should be cleaned with water and mild soap. Never use acid, solvents or anything based on this.

- The lifetime is depending on frequency and conditions of using. For determination of life time user have to cheque product and to evaluate eventual damage according to the previous chapters.

The using lifetime of the products is dependent on the frequency and conditions under which it is used (salt, moisture, chemicals, etc.) and the method of storage and transportation (if it is dry and transported in appropriate boxes or bags). The using lifetime of metal products specified by the manufacturer is unlimited. Products with elements of textile or plastic parts after 10 years from the date of using start (this date must be entered in the card user) and not later than 13 years from the production date, must be submitted to the control of the manufacturer or the person / company authorized by the manufacturer to determine the suitability of the product for further use. A product must be retired when: It is over 10 years old and it is made of plastic or textiles - after this time has to checked by manufacturer or by the person authorized by the manufacturer for further use. When It has been subjected to a major fall (or load). It fails to pass inspection. You have any doubt as to its reliability. When it becomes obsolete due to changes in legislation, standards, technique, or incompatibility with other equipment. Destroy retired equipment to prevent further use.

- WARNING: an exceptional event can lead you to retire a product after only one use, depending on the type and intensity of usage and the environment of usage (harsh environments, marine environment, sharp edges, extreme temperatures, chemical products...).

- Leave it to dry in a well ventilated area, away from sources of heat. Store the harness away from humidity ultraviolet light.

- Avoid any corrosive atmosphere and excessive heat or cold.

The product is covered by a 2 year warranty. Against all material or manufacturing defects. Exclusions: normal wear and tear, oxidation, modifications or alterations, incorrect storage, poor maintenance, negligence, uses for which this product is not designed.

A conformity assessment was performed by notified body 1019 VVUU a.s. Pikarska 1337/7, 716 07 Ostrava Radwanice, The Czech Republic

Declarations of conformity are available on the manufacturer's website www.jmpinter.com and / or are attached to the product and / or to the email address: jmpinter@jmpinter.com

Manufacturer: JMP international sp z o.o., address: Czyżykowa 9, 85-449 Bydgoszcz, Poland, www.jmpinter.com

Trade mark
Catalogue no
name
Size Production date(TT – week; AA – year)
material
serial no (AA/XXXX/NN)
conformity with standards (AAAA – year)
no of supervision notified body
please read the instruction manual
manufacturer logo
manufacturer phone no
manufacturer web site



